TOP AND CONSOLE PARTS

29"GAS DRYER

For Model: WGD6200SW0

(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Model: WGD6200SW0

(White)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	W10054090	Guide, Quick Start
	W10054080	Use & Care Guide
	W10054160	Wiring Diagram

Following May Be Purchased

DO−IT−YOURSELF REPAIR MANUALS

	677818	Dryer
2	8563976	Assembly, User Interface
3	W10110326	Panel Console
4	W10003770	Screw, 6−19 x 3/64
5	717252	Plug, 2 Way Terminal
6	8564265	Cover, Rear UI−Assembly
7	8574957	Knob Assembly
8	337686	Screw, 8−18 x 1/2
9	94614	Terminal, Female
10	8572270	Assembly, Lint Screen
11	W10044320	Cover, Lint Screen
12	W10044470	Hinge, R.H.
	W10044480	Hinge, L.H.
13	W10001580	Screw, 8−18 x 5/8
14	3936144	Connector
15	3395683	Connector (Motor)
16	8565021	Top
17	343641	Screw, 10−16 x 1/2
18	8558863	Bracket, Console
19	3394427	Clip−Harness
20	94613	Terminal
21	8563853	Bracket, Machine Controller
22	W10074280	Control, Electronic
23	3347243	Connector 6−Circuit
24	353424	Connector Sensor
25	3401144	Connector, (PTS Relay)
26	3403499	Connector, 2−Position (Gas Valve)
27	3403498	Connector, 3−Position (Gas Valve)
28	8299917	Harness, Wiring
29	8558853	Screw, Grommet (2)

CABINET PARTS

For Model: WGD6200SW0

(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Model: WGD6200SW0

(White)

Illus. No.	Part No.	DESCRIPTION
1	8533974	Screw, Ground
2	3390631	Screw, 10−16 x 1/2
3	693995	Screw, Hex Head
4	3387374	Spring, Idler
5	8558833	Cover, Terminal Block
6	8566208	Assembly, Switch
7	8558830	Panel, Rear
8	8568303	Locator, Snap Down
9	8572983	Door Strike
10	3978977	Door Switch Assembly
11	3389420	Retainer−Idler 1/4−20 x 1/16
12	W10050060	Filler Door
13	8578538	Belt Restrainer
14	8578560	Hole−Plug
15	8565018	Assembly, Hinge & Pin
16	3392100	Foot, Dryer
	279810	Foot−Optional (Extended Length) (Package of 2) (Not Included.)
17	342055	Screw, 8−18 3/64
18	8557569	Cabinet
19	W10007520	Clip, Ground (2)
20	8576625	Lock, Front Top (2)
21	8565033	Panel Front (Includes Illus. 34)
22	8564011	Bracket, Switch
23	3404413	Plug−Hole
24	8572982	Assembly, Door Catch
25	8575027	Seal, Door
26	308499	Pal Nut (4)
27	8539897	Jumper, (Belt Switch)
28	W10100830	Screw, 10−16 x 3/64
29	8539897	Screw
30	8565020	Door Inner
31	8565038	Door Outer
32	8575033	Handle, Door
33	W10044490	Seal, Front Panel
34	8564457	Plug, Front Panel
35	344020	Power Cord
36	3394083	Clip, Front Panel
37	238088	Hinge, Top (2)
38	8547174	Idler & Pulley Assembly
39	8547168	Belt, Drive
40	8547166	Base Motor
41	W10002600	Screw
42	8578565	Pulley, 60 HZ
43	8566152	Motor, Assembly 60 HZ
44	660658	Clamp, Motor
45	8557890	Burner, Assembly 60 HZ (See Pages 7 & For Further Burner Breakdown)

BULKHEAD PARTS

For Model: WGD6200SW0
(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Model: WGD6200SW0

(White)

Illus. No.	Part No.	DESCRIPTION
1	8544805	Lint Chute Assembly
2	489463	Screw, 8−18 x 5/8
3	3387459	Washer−Support
4	347139	Seal, Lint Chute
5	90767	Screw, 8−18 x 3/8
6	487909	Screw, 8−15 x 1/2
7	3196537	Screw, 8−18 x 3/8
8	8539889	Harness, Flame Switch
9	8577274	Thermister, Internal−Bias
10	694089	Wheel, Blower
11	8577230	Housing, Blower
12	8546149	Clip−Heater Box
13	343641	Screw, 10−16 x 1/2
14	8544803	Box, Heater
15	3403140	Thermostat, 205°F (96°C)
16	8544810	Collar, Lint Chute
17	8558890	Bulkhead, Front
18	8066049	Funnel, Burner
19	3403634	Socket Assembly
20	3406124	Bulb
21	8544813	Seal, Lint Chute
22	3977373	Bracket, Drum Light
23	8565688	Baffle, Drum (3)
24	8557270	Drum, Assembly
25	280010	Kit, Thermal Cut−Off (Includes Illus. 15)
26	3401707	Wire, Jumper
27	3934666	Nut, 3/8−16 (R.H.)
28	8573836	Shield, Exhaust
29	W10109200	Screw, 11−16 x 3/4
30	8576468	Pad, Sensor
31	8557277	Seal, Drum
32	3402841	Lens, Drum Light
33	338906	Sensor, Radiant
34	8557242	Bulkhead
35	W10001120	Nut, 3/8−16
36	8536973	Roller Support
37	8575324	Shaft (R.H.)
38	8575325	Shaft (L.H.)
39	690997	Ring, Tri
40	W10053480	Bracket, Lint Chute

8557890 BURNER ASSEMBLY

For Model: WGD6200SW0
(White)

USE WITH TYPE 1 − NATURAL
AND TYPE 4 LIQUEFIED PROPANE AND BUTANE GASES



Illus. No.	Part No.	DESCRIPTION
1	8557890	Burner Assembly 60 Hz. (Type 1) (White Rodgers)
2	688617	Tube, Burner
3	694298	Bracket, Ignitor
4	686590	Ignitor
5	3393909	Screw & Washer (8−32 x 7/8)
6	3390631	Screw, 10−16 x 3/8
7	8544751	Base, Burner
8	3387057	Screw, 8−18 x 3/8
9		Orifice, Burner
	234826	Type 1
	229742	Type 4 (Butane)
	234868	Type 4 (Propane)
10	8281924	Valve, Gas 60 Hz. (Complete) (Includes Pipe & Illus. #7).
11	694421	Screw, 8−32 x 1/2 (2)
12	8182790	Bracket, Coil
13	694540	Coil, 60 Hz. (2 Terminal) (Main)
14	694539	Coil, 60 Hz. (Split) (3 Terminal) (Pilot Position)
15	694424	Leak, Limiter
16	694423	Screw, Regulator Adjustment
17	694422	Spring, Regulator

Following Parts Not Illustrated

	49572	Conversion Kit (Type (1) to Type (4) LPG).

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Model: WGD6200SW0
(White)

Illus. No.	Part No.	DESCRIPTION
		ACCESSORY PARTS
	279948	Kit, Dryer Repair
	346764	Kit, Hold−Down (Gas Dryer Mobile Home Installation)
	W10071550	Dry Rack
	8522199	Kit, Dryer Vent Testing
		PAINT, TOUCH−UP (1/2oz.)
	72017	White
		PAINT, PRESSURIZED SPRAY (12 oz.)
	350930	White
	350938	Primer, Gray
		PAINT, BULK (1 qt.)
	799344	White (Uncut)